

## Changing Video Output to Analog on Camera Model:

### EC1HDAIRD2M24

**Step 1:** Plug the power end of the camera into a power source.

**Step 2:** Plug the video end of the camera into the device you will be using such as a DVR, TV, or any other video viewing device.

**Step 3:** Using the OSD Menu button located on the camera's cable (Fig 1.) push and hold the joystick up for 5 seconds to change the device to CVBS for analog systems.



(Fig 1.)

